The following upgrade instructions are in relation to updating the firmware by copying an update file to the SD Card via the supplied USB cable. Our Dash Cams can also be updated via MyNextbase Player® (NBDVR222 and above).

	Windows	Mac

1 Download the latest version of firmware for the NBDVR222G via the Support & Downloads page for your Dash Cam.

Windows: [Download Here](#)

Mac: [Download Here](#)

2 The firmware update will be saved to your PC as a file called 'FW222GA. This will usually be located within the downloads folder on your computer.

Note: You won't be able to open this file on your computer.

FWXXXX.bin

FWXXXX.bin

3 Right click (CMD & click if using a mac) on the bin file inside the downloads folder and select the option that says 'Copy'.

Open with
Scan with Windows Defender...
Share

Give access to
Add to archive...
Add to "FW322GWA.rar"
Compress and email...
Compress to "FW322GWA.rar" and email
Restore previous versions

Send to

Cut
Copy

Create Shortcut
Delete
Rename

Properties

Open
Open With ▶

Move to Trash

Get Info
Rename
Compress "FWXXXX.bin"
Burn "FWXXXX.bin" to Disc...
Duplicate
Make Alias
Quick Look "FWXXXX.bin"
Share ▶

Copy "FWXXXX.bin"

Clean Up Selection
Show View Options

4 Go to the Dash Cam Setup Menu (Press the Menu button twice when the camera is not recording) and select the option that says Format SD Card', press the 'OK' button to confirm.

Setup Menu
Format SD Card
Time & Date
Language
Screen Saver
MENU Back   Enter OK

Setup Menu
Format SD Card
Time & Date
Language
Screen Saver
MENU Back   Enter OK

5 Plug the Dash Cam into your Desktop using the supplied USB cable and press the 'OK' button to select the 'Firmware Update' option.

PC Connection
Access Files
Power On
Firmware Update

Enter OK

PC Connection
Access Files
Power On
Firmware Update

Enter OK

6 The Dash Cam should the appear as a storage device called 'NEXTBASE' within File Explorer (Windows) or Finder (Mac).

evices and drives (5)

Local Disk (C:)
503 GB free of 930 GB

DVD RW Drive (D:)

Local Disk (E:)
55.9 MB free of 449 MB

NEXTBASE (G:)
28.9 GB free of 28.9 GB

Removable Disk (H:)

Recents
iCloud Drive
administrator
Documents
Desktop
Applications
AirDrop

Devices
Remote Disc
NEXTBASE

7 Click on your SD card as it appears within File Explorer/Finder to view the contents of the card.

Devices and drives (5)

Local Disk (C:)	Local Disk	
DVD RW Drive (D:)	CD Drive	
Local Disk (E:)	Local Disk	
NEXTBASE (G:)	Removable Disk	
Removable Disk (H:)	Removable Disk	

NEXTBASE

Favorites
Recents
iCloud Drive
administrator
Documents
Desktop
Applications
AirDrop

Devices
Remote Disc
NEXTBASE

Shared
nextbase-03
robpc
WalesServer

NEXTBASE

8 Once the contents of the card are displayed, right click in the white space and select the option that says 'Paste'.
This will copy the file from your downloaded zip file and place it onto the SD card where it can be read by the Dash Cam.

View
Sort by
Group by
Refresh

Customize this folder...

Paste
Paste Shortcut
Undo Move   Crtl+Z

Give access to

New

Properties

New Folder

Get Info

Paste Item

View
Clean Up
Clean Up By
Arrange By
Show View options

9 Please ensure that the bin file is NOT renamed in anyway, the update will fail if the file appears as FW222GA(1).bin, for example.

FWXXXX.bin

FWXXXX.bin

10 Once you have copied 'FW222GA.bin' to the Dash Cam you can now unplug the Dash Cam from your PC. It will shut down and you will see the Nextbase logo.

NEXTBASE

NEXTBASE

11 After the Dash Cam has shut down completely, plug it back into your PC and select 'Power On'.
The update should begin automatically.

Firmware Updating...
Update takes approx 1 minute

Do not disconnect power!

Firmware Updating...
Update takes approx 1 minute

Do not disconnect power!

**12** After the update has installed your Dash Cam will restart and display the PC Connection Screen.
Select the 'Power On' option using the 'OK' button to continue.

PC Connection
Access Files
Power On
Firmware Update

Enter **OK**

PC Connection
Access Files
Power On
Firmware Update

Enter **OK**

13 After the Dash Cam has restarted open the Setup Menu (by pressing the 'Menu' button twice) and scroll down to 'System Info'. Press the 'OK' button to select this option and the Firmware version will be displayed.

System Info
Model:	222G
Firmware:	Rxx.x
Serial No:	123456789
FCC ID:	2AOT9-NBDVR222G
Battery Status:	Charging

⬅ ● ○ ○

System Info
Model:	222G
Firmware:	Rxx.x
Serial No:	123456789
FCC ID:	2AOT9-NBDVR222G
Battery Status:	Charging

⬅ ● ○ ○

NEXTBASE
Dash Cams

✉   📞   🌐   🔧   www.nextbase.com